

**PP-8000 Jumper Setting**

## ● SWITCH 1:

SWITCH 1		FUNCTION
1 OFF	2 OFF	Baud Rate 19200
1 OFF	2 ON	Baud Rate 115200 ● Serial Default ● Parallel Default (couldn't be changed)
1 ON	2 OFF	Baud Rate 9600
1 ON	2 ON	Baud Rate 38400
3	OFF	OFF: None
	ON	ON: Even
4	OFF	OFF: DTR/DSR
	ON	ON: XON/XOFF
5	OFF	OFF: Busy when buffer full and off line
	ON	ON: Busy when buffer full
6	OFF	OFF: Normal Cut
	ON	ON: Cut and no feed.
7	OFF	OFF: <CR> Invalid
	ON	ON: <CR>Valid.
8	OFF	Reserved. Fixed to OFF.

## ● SWITCH 2 :

SWITCH 2		FUNCTION
1	OFF	Buffer data then batch printing. (When using printer driver)
	ON	PP-7000 like. (When using printer driver)
2	OFF	80mm(Paper Wide)
	ON	58mm.
3	OFF	512 dots
	ON	576 dots.
4	OFF	OFF: No Water proof cover
	ON	With water proof cover (Immediately cut paper when cover closed)

